

## User Management

### Add toolbar button for User settings backup

With 2D Software it is possible to copy all User settings of a WinARace installation to a synchronizing directory, such as a server or a USB stick.

The upload to a server or USB stick can either be used as a backup functionality or to share/copy User settings to other PC.

Each time a 2D module is **read into WinIlt** or **the setting is sent to the module via apply**, the current setting of the module is saved in a WinARace directory to ensure that it is always possible to step back to an older, correct setting of the module.



#### Documentation reference

For more information about backing up user settings please see the manual **User Management – Manual User settings backup** on our website:

<http://2d-datarecording.com/downloads/manuals/>



#### Documentation reference

For more information about integrating backed up User settings on a new PC please see the manual **User management – Integrating User settings** on our website:

<http://2d-datarecording.com/downloads/manuals/>

**In this manual it is described how to add required toolbar button for User settings backup.**

1. Open *WinARace* and open *Folders - Protocolls* folder via *WinARace-Tab Settings* and open *Application data directory* by clicking on the button with respective path



#### Further Information

Instead of opening *Folders – Protocolls* also shortcut [CTRL]+[ALT]+[D] can be used with *WinARace* opened!

2. Open *Toolbar.ini* with a text editor
3. Close **all** currently running 2D applications on your computer



#### Important information

It is very important to close all currently running 2D applications that the **.ini-files are saved correctly at next steps!**

4. Insert the following group after last existing [group] of *Toolbar.ini* and change number of inserted group **XX** to next value and change the **Race-version** to the currently used.

[PROGRAM\_XX]

LinkName=2D\_COPY\_RACE\_SETTINGS\_TO\_SERVER.BAT

OnlyEvent=0

CompleteEventPath=0

OnlyMeasure=0

CompleteMeasurepath=0

LoggerName=0

NewdataFormat=0

AdditionalParameter=<SETTINGSYNCDIR> <RACEVER> <APPDATADIR> <USERDATADIR> <DATADIR> "<RACEDIR>"

ShortCut=0

Sequential=0

SingleRunEachSelectedMeasurement=0

WaitForTermination=1

Comment=Copy Race-Settings TO Server#

IconLinkName=C:\ProgramData\Race2021\System\Bilder\2D\_Sync.bmp

5. Save and close *Toolbar.ini* file and open *WinARace* again
6. Check if the new toolbar button is added correctly.

